




Tech Dept.
(630) 957-4019

Tech@powermasterperformance.com

WIRING INSTRUCTIONS

Ford Upgrade Alternator 100/150 Amp



Replaces these OEM Alternators






OEM Ford 2G
Int Regulator
1987-93



OEM Ford 1G
External Regulator
1965-86

Charge Post Size
12-24 for 100 Amp
5/16-18 for 150 Amp

Optional Charge Indicator Light Function: Your Powermaster Alternator is designed to work as a 1 wire without any connections to the plug in. The function of the plug is to run a charge indicator (Idiot Light) only. This plug also does not serve as a hookup point for a voltmeter, or help charging at idle. **This connection has no effect on charging performance.**



Charge Ind. Light



From Ignition Switch

NOTE: On 1986-1993 vehicles with Plug in style power cables use new 8-6 gauge charge wire in place.



BATTERY + ON
STARTER SOLENOID

Disconnect Battery Negative (-)

READ ALL INSTRUCTIONS IN BOX!

Charge Wires: (DO NOT Use OEM Battery Plug-in)

100 Amp Alt. use 8 gauge up to 6 ft.

150 Amp Alt. use 6 gauge up to 6 ft.

Alternator Ground: Many mounting brackets are powder/clear coated, painted, or plated. The alternator will not ground properly without a ground wire from the Alt. housing to the engine block. (This wire should match charge wire size)

Battery must have a clean ground to engine block.

Wire Connections: Be sure all terminals are crimped securely, and connections are clean and tight.

Belt Tension: Inspect belt for signs of cracking or glazing. Replace if needed. **A loose belt will cause intermittent charging and generate excessive heat resulting in premature unit/bearing failure.**

For V belt units follow attached pulley tag.

A fully charged battery is at least 12.6V, not 12.0V. A weak/defective battery will cause premature failure. **Never disconnect the battery with engine running!** This causes voltage spikes that will damage the alternator.

DO NOT EXCEED 18,000 ALTERNATOR SHAFT RPM
(See Catalog pg.45 for more info)

FAILURE TO FOLLOW THESE INSTRUCTIONS MAY VOID YOUR WARRANTY

Warranty void if unit is soaked in Oil or Mud