

Throttle Bracket Locations for 1969 and 1970 Mustang Cars

To accommodate the locations of the throttle brackets in these cars, the firewall insulator is perforated for both locations. Use the pilot holes and the guide below to determine which set of perforations you will need to cut out.

Once you have determined which bracket location your car requires, cut the "perf chads" with an Xacto type knife and remove the rubber. Then, trim the insulation material to fit the cut-out.

Install the Firewall insulator and then install the throttle bracket.

