



Thank you for purchasing our Cougar front fender rubber splash shield kit.

Installation of the enclosed parts is very simple using the following suggestions:

- Place each of the rubber splash shields against its respective steel panel using the stamped shape for proper alignment.
- Use a 1/16" drill bit to make holes for the staples. Drill one hole and use a staple to mark the location (distance) for the second hole. If used against the steel panel it will act as a scribe.
- Insert the staples. Push hard through the rubber and bend over the exposed staple end on the other side.
- Reinstall the completed panels on the car with the proper hardware.

Note that on the original splash shields photographed below, consistency and perfection was not highest consideration! The staples are not evenly spaced. The rubber is not perfectly aligned. We have one original sample that actually had some Mustang rubber parts attached to it!

Included with this rubber kit are stainless steel wire staples very similar to what was used originally.

The finished job will reflect attention to detail and offer protection to the vital under-fender areas of your Cougar.

1967



1968

