

Red = 12V switched
Black = Ground
Green = Signal*

*Signal can come from
MSD tach port or distributor
(-) side of coil.

Notes:

1. Install jumper in factory tachometer connector to complete ignition (+) circuit to coil.
2. OEM tach wiring may be used as 12V power source.

