

# Pop Open Fuel Cap Installation Instructions

Courtesy National Parts Depot.

If you choose to install the pop open cap parts that mimic the original design do so at your own risk. Ford discontinued this cap arrangement due to several law suits stemming from fuel spills in rear end accidents. The free standing fuel cap fits under the pop open door and attaches directly to the fuel filler pipe resulting in a safer arrangement. Installing the OE style components must be done with the full understanding of the safety issues involved. Installer and end user assume ALL liability with this installation.

Emblem is installed with a 3/16" nut driver. Place the emblem on the cap and support the two on a block of wood. I added a couple poly bags to prevent marring the chrome. Install the sheet nuts with the nut driver using a firm push. Make certain the fingers of the sheet nuts are completely on the emblem posts to keep them from popping off. Image #1



To install the OE style fuel seal components:

- 1) Assume all liability for this installation.
- 2) Install the spring and large cap using the bolt and washer provided. Screw it down firmly but do not over torque it. Image #2
- 3) Place the rubber gasket in the center of the large cap and align the small screw holes. Place small cap on the gasket and install the 4 small screws provided, firmly but do not overtighten. Image #3
- 4) Install finished cap (image#4) on filler tube/taillight panel.

