



New Parts for
OLD FORDS & HOT RODS
1932-59 Ford Cars • 1932-66 Pickups

(800) 221-FORD • Fax: (541)474-0099
www.bobdrake.com

Installation Instructions

Shift Link Repair Kit

01A-7354-RK

1940-51 Car, 1940-55 Pickup

INSTRUCTIONS

STEP 1: SHIFT LINK REPAIR

1. Assemble Insulator, Bushing and Washer into Clevis/Shift Arm as shown.
2. Always wear safety glasses when using Swaging Tool. On stable flat surface, fasten Bushing using provided Swaging Tool and hammer or press as illustrated. Carefully file prior to final installation.

