



## Mustang 5.0 Injector Harness Installation Instructions



These Instructions Cover the Following Part Numbers:

FH-093      1987-1993 Ford Mustang 5.0 Injector Harness

## Installation Instructions:

- 1) Disconnect battery
- 2) Installation will be easier if upper plenum is removed.
- 3) Remove factory harness, taking note how wires are run. Disconnect main black and white connectors at back of engine.
- 4) Install replacement harness following factory routing. Make sure ground lug has clean metal and will make good contact to intake bolt.
- 5) Complete installation by confirming harness is routed away from exhaust and any moving parts.

Ron Francis Wiring  
200 Keystone Rd.  
Chester, PA 19013  
800-292-1940  
[www.ronfrancis.com](http://www.ronfrancis.com)

## Warranty Information

All Ron Francis Wiring products are warranted for 1 year from purchase date. There are no other representations, warranties or conditions expressed or implied, statutory or otherwise except those herein contained. Warranty does not cover any defect which is the result of improper installation or modification of the system or any of its components by purchaser.

Ron Francis Wiring, its dealers or agents will not be liable, in any way, for any damage, loss, injury or other claims, resulting from the use or misuse, or inability to use any of our products. Purchaser and/or user, assumes liability of any kind connected with the use and/or application of our products.

Copyright © 2006 Ron Francis Wiring