

Red = 12V switched  
Black = Ground  
Green = Signal\*

\*Signal can come from  
MSD tach port or distributor  
(-) side of coil.

Notes:

1. Install jumper in factory tachometer connector to complete ignition (+) circuit to coil.
2. OEM tach wiring may be used as 12V power source.

